



**Ribbon Cartridge Installation / 色带安装说明 / 色带安装说明**



**Button/按钮/按钮**


Warning/高温勿触/高温勿触




**Anchor/卡榫**

**Photo Paper Installation / 相纸安装说明 / 相纸安装说明**


Please touch paper's margin only  
 拿取纸张时, 请手握纸张的边缘  
 拿取纸张时, 请手握纸张的边缘



Make sure load paper with glossy side facing down,  
 detachable border toward paper door button  
 放置相纸时光滑面需朝下、折撕边需朝纸门按钮  
 放置相纸时光滑面需朝下、折撕边需朝纸门按钮




**detachable border/折撕边/折撕边**




P/N:64.P3000.001

**Transparent Film & Sticker Installation / 相纸安装说明 / 相纸安装说明**


Please touch paper's margin only  
 拿取纸张时, 请手握纸张的边缘  
 拿取纸张时, 请手握纸张的边缘



Make sure load paper with glossy side facing down,  
 detachable border toward paper door button  
 放置相纸时光滑面需朝下、折撕边需朝纸门按钮  
 放置相纸时光滑面需朝下、折撕边需朝纸门按钮



**detachable border/折撕边/折撕边**



P/N:64.P3000.001